

STAINLESS STEEL BOX GANGWAY WITH SPECIAL TROLLEY 1103



| model | A (mm/inch) | B (mm/inch) | C (mm/inch) | L (mm/inch) | H (mm/inch) | α | β | loading optional (kg/lbs) | weight (kg/lbs) |
|----------|-------------|-------------|-------------|-------------|-------------|----------|---------|---------------------------|-----------------|
| 1103/21* | 2130 84" | 1740 69" | 200 7" 4/5 | 550 21" 2/3 | 230 9" | 15° | 15° | 150/330 | 200/440 |
| 1103/29 | 2900 114" | 2140 84" | 200 7" 4/5 | 550 21" 2/3 | 230 9" | 15° | 15° | 150/330 | 232/510 |
| 1103/35 | 3460 136" | 2340 92" | 200 7" 4/5 | 550 21" 2/3 | 230 9" | 15° | 15° | 150/330 | 275/600 |
| 1103/38 | 3755 147" | 2540 100" | 200 7" 4/5 | 550 21" 2/3 | 230 9" | 15° | 15° | - | 318/700 |
| 1103/40 | 4035 159" | 2660 105" | 200 7" 4/5 | 550 21" 2/3 | 230 9" | 15° | 15° | - | 333/735 |
| 1103/43 | 4345 171" | 2800 110" | 200 7" 4/5 | 550 21" 2/3 | 230 9" | 15° | 15° | - | 353/780 |
| 1103/44 | 4425 175" | 2900 114" | 300 12" | 550 21" 2/3 | 230 9" | 15° | 15° | - | 360/795 |
| 1103/45 | 4540 179" | 3000 118" | 400 16" | 550 21" 2/3 | 230 9" | 15° | 15° | 150/330 | 371/820 |
| 1103/47 | 4710 186" | 3340 131" | 600 24" | 550 21" 2/3 | 230 9" | 15° | 15° | - | 407/900 |
| 1103/50* | 5040 199" | 3440 136" | 500 20" | 550 21" 2/3 | 230 9" | 15° | 15° | - | 440/970 |
| 1103/53* | 5295 208" | 3350 132" | 300 12" | 550 21" 2/3 | 230 9" | 15° | 15° | - | 455/1000 |
| 1103/54* | 5400 213" | 4100 161" | 1350 53" | 550 21" 2/3 | 230 9" 5/6 | 15° | 15° | - | 497/1095 |
| 1103/58* | 5800 228" | 4100 161" | 800 32" | 550 21" 2/3 | 230 9" | 15° | 15° | - | 542/1190 |

This gangway allows the boarding of 150 Kg / 330 lbs maximum (one person at a time).

The equivalent model in series 1133, but box height 195 / 7 2/3.

CUSTOMIZATION FOR TENDER LIFTING CAN BE REQUIRED.

• Available with larger box optionals 510/590/660/710 mm. / * Manual stanchions only.

A= maximum length of gangway outside of the box

B= box length

C= distance between the gangway hinges and the box

H= box height

L= box width

α and β = the total angle the gangway can achieve.

NEVER USE THE GANGWAY AS SPRINGBOARD. DIVING COULD CAUSE STRONG STRAINS THAT MIGHT DAMAGE THE GANGWAY AND ITS FASTENING ELEMENTS.

| L_box (mm/inch) | G (mm/inch) | F (mm/inch) | M (mm/inch) |
|-----------------|-------------|-------------|-------------|
| 660 26" | 550 21" 2/3 | 410 16" 1/6 | 515 20" 1/4 |
| 710 28" | 600 23" 2/3 | 460 18" | 555 21" 4/5 |
| 590 23" 1/4 | 470 18" 1/2 | 340 13" 2/5 | 435 17" |
| 550 21" 2/3 | 430 17" | 300 11" 4/5 | 395 15" 1/2 |
| 510 20" | 390 15" 1/3 | 260 10" 1/4 | 355 14" |

